

# ATUC-IRDU Firmware Update Tool User Manual

This document describes how to use the ATUC-IRDU firmware update tool.

1. Connect ATUC-IRDU and PC with micro USB cable.



2. Micro USB connector is on the back of ATUC-IRDU.



3. Hold down [+]button and [-]button on right side and turn on power switch.




4. If multifunction button icon is blinking, startup in the firmware update mode is successful.




5. Launch ATUC-IRDU Firmware Update Tool.




6. Select COM port.




7. Click [Browse File] button.




8. Select F/W update file.




9. When select a file, version and revision are displayed.



10. Click [Update Start] button.



11. Update begins.



12. If following message is displayed, update is completed.

